

## FastSLAM Project Pt. 1

### FastSLAM Implementation

FastSLAM is a Rao-Blackwellized particle filter for simultaneous localization and mapping. The pose of the robot in the environment is represented by a particle filter. Furthermore, each particle carries a map of the environment, which it uses for localization. In the case of landmark-based FastSLAM, the map is represented by a Kalman Filter, estimating the mean position and covariance of landmarks.

Implement the landmark-based FastSLAM algorithm as presented in the lecture and using the Webots simulator. Assume known feature correspondences.

To support this task, we provide a detailed listing of the algorithm as a PDF file and a Webots framework in the archive `fast_slam.zip`. The archive, among others, contains the following folders:

**worlds** contains the Webots world file `fast_slam.wbt`.

**controllers** contains the corresponding controller file `fast_slam_controller.py`. That file already contains a FastSLAM framework where you need to fill in the blanks in the code.

- (a) Familiarize yourself with the Webots simulator. First, download and install the version for your system from <https://cyberbotics.com> (available for Windows, Mac, and Linux). Then, follow the official tutorial at

<https://cyberbotics.com/doc/guide/tutorial-1-your-first-simulation-in-webots>

After that, open `fast_slam.wbt` in the simulator. The world contains a Pioneer robot and several objects that are considered as landmarks. You can control the robot using the arrow keys. After moving the robot, a plot will appear that shows the map of the environment and the estimated robot trajectory. However, the algorithm will only work correctly after you complete the code in `fast_slam_controller.py` as described below.

- (b) Complete the code blank in the `sample_motion_model` function by implementing the odometry motion model and sampling from it. The function updates the poses of the particles based on the old poses, the odometry measurements  $\delta_{rot1}$ ,  $\delta_{trans}$  and  $\delta_{rot2}$  and the motion noise. The motion noise parameters are:

$$[\alpha_1, \alpha_2, \alpha_3, \alpha_4] = [0.1, 0.1, 0.05, 0.05] \quad (1)$$

- (c) Complete the code blanks in the `eval_sensor_model` function. The function implements the measurement update of the Rao-Blackwellized particle filter, using range and bearing measurements. It takes the particles and landmark observations and updates the map of each particle and calculates its weight  $w$ . The noise of the sensor readings is given by a diagonal matrix

$$Q_t = \begin{bmatrix} 1.0 & 0 \\ 0 & 0.1 \end{bmatrix} \quad (2)$$

- (d) Complete the function `resample_particles` by implementing stochastic universal sampling. The function takes as an input a set of particles which carry their weights, and returns a sampled set of particles.